ø80 and ø100 rainwater collector

Building





Nicoll's range of rainwater collectors now includes a solution which combines great looks, a generous collection capacity, and the durability of our PVC.

ADVANTAGES:

- Maximises rainwater collection
- Combines neatly with the downpipe
- Connects quickly and easily to a storage tank
- Quick to install with no need for gluing
- Easy maintenance
- Colours that really last
- 'Quarter turn' to open or close





BUILDING

SANITARY ENVIRONMENT

ø80 and ø100 rainwater collector

Building



REFERENCES

DESCRIPTION	REF. GREY	REF. WHITE	REF. SAND	REF. BROWN	REF. SLATE	REF. BLACK	REF. COPPER	PRICE €
ø 80 rainwater collector	REPTD80	REPTD80B	REPTD80S	REPTD80M	REPTD80A	REPTD80N	REPTD80C	€29.30
ø 100 rainwater collector*	REPF100	REPF100B	REPF100S	REPF100M	REPF100A	REPF100N	-	€49.90

* The 100 diameter model is an adaptor and does not have the «open/closed function.


TECHNICAL CHARACTERISTICS

- Anti-UV treated PVC
- Open/closed position switched by simple rotation
- 26x34 outlet/versatile connection options:
 - interlocking fitting for watering pipes
 - (26x34 and with reducer 20x27)
 - ball valve or brass fitting
- Over 90% efficiency at a flow rate of 1 m³/h

NICOLL ADVANTAGES

In order to filter out leaves and other objects passing through the downpipe, Nicoll recommends incorporating a leaf trap and positioning this 25 cm above the REPTD80. (Please see p. 178 of the 2013 price list for references for this product.)


INSTALLATION



Decide where to position the collector on the downpipe. Then cut the pipe based on the length of the cutting template as shown on the back of the packaging. Remove the lower section of the downpipe.



With a pencil, mark the maximum depth of the interlocking section using the raised marking at the top of the collector.



3

a) Align the collector with the downpipe, then interlock the two until you reach the mark.

b) Next, insert the lower section of the downpipe until it can go no further and secure this with downpipe brackets.



115 mm

56

Attach to the tank. Set the collector to the open position so it can supply the tank.

Note: To ensure the overflow function works, align the raised marking with the top of the tank.

OTHER COLLECTOR MODELS

Page 278 of the 2013 price list has details of the models adapted to the Ovation downpipe, as well as models with cleats.



Head office and industries: 37, rue Pierre et Marie Curie - BP 10966 - 49309 CHOLET Cedex // Tel. +33 (0)2 41 63 73 83 - FAX +33 (0)2 41 63 73 57 - www.nicoll.fr Email: info@nicoll.fr // Technical information: tech-com.nicoll@aliaxis.com // SAS (PLC) with a working capital of 7 683 431 euros - 060 200 128 RCS Angers

